

GRANT ADAPTER RING INSTALLATION INSTRUCTIONS

MODEL 4007 – GRANT 5-BOLT (SIGNATURE) WHEEL TO STANDARD LeCARRA KIT (NOT FOR USE ON BILLET STYLE KITS, HUB MUST HAVE OUTER FLANGE WITH THROUGH BOLTS)

Position adapter ring on hub with arrow stamped on ring at the top position. Use the nine socket screws provided to secure the adapter ring to the LeCarra hub and tighten securely to 10-12 ft/lbs. Proceed with normal installation procedures found with your GRANT Custom Steering Wheel.

MODEL 4008 – GRANT 5-BOLT (SIGNATURE) WHEEL TO MOMO HUB KIT

Position adapter ring on hub with arrow stamped on ring at the top position. Use the five (5) metric screws provided to secure the adapter ring to MOMO hub and tighten securely to 10-12 ft/lbs. Proceed with normal installation procedures found with your GRANT Custom Steering Wheel. **NOTE-** On solid MOMO kits with a small flange (or lip) on top, you must first cut or machine this flange off flat with the hub mounting surface.

MODEL 4009 – MOMO WHEEL TO GRANT 5-BOLT HUB KIT (EURO OR BILLET KITS ONLY) (YOU MAY ALSO USE 3000 OR 4000 SERIES KITS IN CONJUNCTION WITH A MODEL 4000 EXTENSION KIT)

Position adapter ring on 5-bolt adapter with the arrow stamped on ring at the top position. Use the four (4) socket head screws provided to secure the adapter ring to the hub kit (leave out the screw at the 12:00 position) and tighten securely to 10-12 ft/lbs. Proceed with normal installation procedures but use the long flat head screw provided in the 12:00 screw hole.

97527-11-01